



NOTES:

- 1) CUTS ARE TO BE MADE CLEANLY WITH A SHARP ROOT PRUNING TOOL (SUCH AS A DOSCO OR VERMEER ROOT PRUNER).
- 2) INSTALL ORANGE PLASTIC MESH TREE BARRIER, WITH REBAR SUPPORTS, AT POINT OF PRUNING AND CONTINUE COMPLETELY AROUND TREE, PROTECTING THE AREA WITHIN THE DRIP LINE (EXTENT OF OUTER BRANCHES).
- 3) ROOT PRUNING PROCEDURE MUST BE DONE AND INSPECTED PRIOR TO ISSUANCE OF A BUILDING PERMIT OR GRADING AND FILL PERMIT.



STANDARD CONSTRUCTION DETAIL

ROOT PRUNING

NTS.

INDEX

LS-2

MAY 2020